
## SafeVision 2 Enhanced No-Line Performance Centration Charts



PRINTING INSTRUCTIONS:

When printing from PDF, select "Actual size" from the Page Sizing & Handling section of the print menu. Not doing so will result in inaccurate sizing