



Spectacle Kit for North Full Facepieces

North Safety Products offers spectacle frames that can be used on all North Full Facepieces. The user must have their prescription lenses fitted to the frames. Check the part number and description of your spectacles and follow the installation instructions below.

<u>Part No.</u>	<u>Description</u>
760024	Metal Spectacle Frame with support wire

Installation instructions:

1. Loosen the head harness on the facepiece to allow room to insert the spectacle frame.
2. Grasp both support arms, flex them slightly inward and place them inside the facepiece, against the facepiece lens and along the perimeter of the rubber edge.
3. Center the complete assembly so the spectacle frame is directly above the nose cup.
4. If adjustment is needed, move the spectacle frame support block up or down or move lens holder in or out of the support block.
5. To remove, grasp one of the support arms and gently remove complete spectacle frame assembly from the facepiece.

North Safety Products
2000 Plainfield Pike
Cranston, RI 02921
USA

North Safety Products
10550 Parkway Blvd.
Anjou, Quebec
Canada H1J 2K4

North Safety Products
Noordmonsterweg 1
4322 SC Middelburg
The Netherlands

©2004 North Safety Products. Printed in U.S.A.

Part No. 46001183 Rev. B